



**New  
Product**

## IATCO Hinged Clutch Brake

Replace worn or damaged  
clutch brakes without  
removing the transmission.

### **IATCO Hinged Clutch Brake:**

The purpose of the clutch brake is to slow down or stop the transmission input shaft from rotating when the clutch pedal is depressed.

Now, with the IATCO Hinged Clutch Brake, you can replace worn or damaged clutch brakes without removing the transmission.

The Hinged Brake, with it's easy installation, not only saves time and money, but also provides effortless engagement and cooler operation.

All brakes include required tools for installation.



**Available in 3  
thicknesses!**

Hinged Clutch Brakes	
M-1393	2" (.390 thick)
M-1738	2" (.465" thick)
M-1739	2" (.500 thick)

**IAT** ILLINOIS AUTO TRUCK  
COMPANY, INC.

1669 Marshall Drive  
Des Plaines, Illinois 60018-1840 USA

Telephone: 847-299-1100  
Toll-Free: 800-842-1712

Facsimile: 847-299-1205  
Toll-Free Fax: 800-942-7660

Website: [www.iatcoinc.com](http://www.iatcoinc.com)  
Email: [sales@iatcoinc.com](mailto:sales@iatcoinc.com)

# **"Best in the Clutch"**